WARRANTY STATEMENT

During the applicable warranty period, any Total Protection Solutions® surge protector device which fails due to defect in materials, workmanship, or any transient surge event to include lightning, shall be repaired or replaced at the expense of the manufacturer.

Prior to shipment of any suspect or known defective product a Return Material Authorization (RMA) number must be obtained. An official RMA number and shipping instructions can be obtained from the distributor where the product was originally purchased. Distributors can obtain the official RMA number by contacting the Total Protection Solutions Customer Service Department at 800-647-1911. Products arriving without an official RMA number will not be accepted and will be returned freight collect to the original point of shipment.

Products being returned with an official RMA number should be shipped by prepaid freight to the nominated point of return as shown on the RMA documentation.

Total Protection Solutions shall have no liability under this warranty for problems or defects directly or indirectly caused by misuse of the Product, alteration of the Product (including removal of any warning labels), accidents, improper installation, application, operation or improper repair of the Product.

THIS WARRANTY REPRESENTS THE ENTIRE WARRANTY OF TOTAL PROTECTION SOLUTIONS. ALL OTHER WARRANTIES EXPRESS OR IMPLIED, ORAL OR WRITTEN, INCLUDING, BUT NOT LIMITED TO, THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. THE LIABILITY OF TOTAL PROTECTION SOLUTIONS, AT ITS SOLE OPTION, UNDER THIS WARRANTY IS EXPRESSLY LIMITED TO THE REPLACEMENT OR REPAIR OF THE DEFECTIVE PART THEREOF. IN NO EVENT SHALL TOTAL PROTECTION SOLUTIONS BE LIABLE OR RESPONSIBLE FOR SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OF ANY KIND OR CHARACTER, NOR SHALL ITS LIABILITY EVER EXCEED THE PURCHASE PRICE PAID FOR SUCH DEFECTIVE PRODUCT.

Warranty period begins from the date of original owner purchase. This warranty is not transferable and may only be enforced by the original purchaser. Claims under this warranty must be submitted to Total Protection Solutions within thirty (30) days of discovery of any suspected product defect.

Warranty Period

PanelTrack®	10 Years

FREE REPLACEMENT
10 YEAR WARRANTY 10 YEAR WARRANTY

Total Protection Solutions®

P.O. Box 3760
Winter Park, FL 32790 USA
1-800-647-1911
www.TPSsurge.com

©2012 TOTAL PROTECTION SOLUTIONS, LLC PRINTED IN USA ALL RIGHTS RESERVED

Total Protection Solutions®

PanelTrack®

Type 2 SPD

AC Surge Protective Device

Series:

TK-PK040-1P240-L
208/277V, Single-Phase, 2 Wire + Ground

TK-PK040-3D240-L
120/240V, 3-Phase, 4 Wire + Ground (Delta)

TK-PK040-3Y480-L
277/480V, 3-Phase, 4 Wire + Ground

TK-PK040-3Y415-L
240/415V, 3-Phase, 4 Wire + Ground

TK-PK040-3Y380-L
220/380V, 3-Phase, 4 Wire + Ground

Installation Operation and Maintenance Manual

INTRODUCTION

The PanelTrack Type 2 Surge Protection Device(SPD) is designed for protection of downstream distribution equipment and wiring as well as most sensitive electrical and electronic loads from the effects of overvoltage transients that might be produced from lightning, induction, load or power factor capacitor switching. Multiple LEDs indicate the functional status of the protection elements within the suppressor.

Important Safety Instructions

All work must be performed by qualified electrical personnel. The electrical system must be properly grounded in accordance with applicable codes for this suppressor to work correctly. The PanelTrack Type 2 SPD must be connected behind a 30A maximum breaker on a system that has a short circuit current rating of 100kAIC maximum.

Installation

The unit must be installed in parallel to the electrical distribution system on the load side of the main service disconnect behind a 30A maximum breaker. Careful consideration should be made in selecting the knockout location because excess lead length and sharp bends in the wire drastically decrease the effectiveness of the SPD. For this reason choose a knockout location that minimizes lead length and sharp bends. The SPD may also be mounted by it's metal bracket within the equipment enclosure.

1. Disconnect all power supplying the electrical panel
2. Remove the panel screws and cover. Retain these parts for re-installation.
3. Either remove a knockout 0.5 inches (13mm) or install provided metal bracket
4. Remove lock washer from the SPDs threaded nipple. Carefully feed the wires through to avoid cutting wire insulation. Slide lock washer over the wires to anchor the threaded nipple. Rotate the SPD so that the function status LED indicators can be easily viewed. Tighten the lock washer to secure the SPD.
5. Locate the neutral bar inside the electrical panel and connect the white or blue wire to the neutral bar and tighten to torque specified on inside of panel. Keep conductor length as short as possible and avoid sharp bends in the wire.
6. Locate the ground bar inside the electrical panel. Connect the green/yellow wire to the ground bar and tighten the terminal to the torque specified on the panel. Keep conductor length as short as possible and avoid sharp bends. If neutral is bonded to ground, green wire may be terminated to neutral.
7. Black or brown wires can be connected to a 30A maximum breaker (# of positions deter mined by the # of black or brown wires provided with the unit). Tighten terminals to torque specified on inside of panel. Keep lead lengths as short as possible and avoid sharp bends.
8. Re-install panel cover.

Operation

1. Apply power to the panel. If the electrical and grounding wirings are done correctly, the green function status LED will illuminate. If the LED is not on, remove the power and review all of the previous installation procedures.
2. If after a known heavy lightning strike has occurred and the LED is off, reset the breaker. If the function LED lights come back on then the protector is fine. If the light is still out, or you can not reset the breaker, the protector must be replaced. This unit contains no user serviceable parts.



CAUTION: Do not assume the circuit is de-energized!
Remove power before performing any maintenance to the device.



TK-PK040-1P240-L



TK-PK040-3D240-L



TK-PK040-3Y380-L TK-PK040-3Y415-L

TK-PK040-3Y480-L

These instructions do not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation operation or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes the matter should be referred to Total Protection Solutions.